

FIBER MANAGEMENT


WALL BOXES

W09-LOCKABLE WALL BOXES 4 POSITION

The wall box system in its basic form is supplied with the box unloaded ready for you to install the adapter of your choice. The box can also be pre-loaded complete with the required adapter and simple splice management kit, or pre-loaded with pigtails to meet your project needs.



LGX0108SCM



LGX0108SCS



LGX0108SCA



LGX0108LCM



LGX0108LCS



LGX0108LCA



LGX0108E2M



LGX0108E2S



LGX0108E2A



LGX0108MTR



LGX0208FCM



LGX0208FCS




LGX0208FCA



LGX0208STM



LGX0208STS



LGX0306SCM



LGX0306SCS



LGX0306SCA



LGX0306LQM



LGX0306LQS



L04